
V 1.0

RTD OEM simple development board

This simple breakout board is designed to help the embedded systems engineer quickly develop a system using Atlas Scientific™ RTD OEM circuit.



1mm Ø

V 1.0

RTD OEM simple development board


The RTD OEM Simple Development Board gives you the option to wire up a 2, 3, or 4 wire temperature probe.



For a **2 wire** set up you will need to short both, the top and bottom jumpers pins.



For a **3 wire** set up only short the bottom jumper pin.



For a **4 wire** set up don't short any of the jumper pins.

2

V 1.0

RTD OEM simple development board

Solder flux residue left on the board can interfere with readings, making accurate readings difficult or impossible to achieve. **Don't be a flux head, remove all solder flux residue from these two spots.**

