

## Dissolved Oxygen Electrolyte Solution

# Instructions

1. Unscrew the pre-membraned cap from the tip of the probe and discard. (**FIG 1**)
2. Remove the cap from the bottle of D.O. Electrolyte Solution. Remove the 10mL syringe from packaging and attach hub needle to end of syringe as shown in **FIG 2**.
3. Use needle and syringe to withdraw 2mL solution from bottle as shown in **FIG 3**.
4. Insert needle into one of the four holes surrounding the silver cathode. Inject solution until it leaks out of a fill hole (**SEE FIG 4**).
5. Replace cap by threading on sensor clockwise (**Opposite of FIG 1**).

